SCHLEIFENBAUER PRODUCT IDENTIFICATION SYSTEM

All product IDs start with **S** (Schleifenbauer)

Customer reference: **3 position alfanumerical code**. This could be a reference to the reseller or to an end user.

Form factor:
H = Horizontal
D = Double Deep Horizontal
V = Vertical
W = Double Deep Vertical

Input:
I = Input metered
N = Basic
C = Definilink Controller
X = Definilink Slave
M = Branch Metered

Outlet:
M = Monitored
S = Switched
B = Managed
P = Inline meter
N = None, passive

Phases:
1 = 1 phase
3 = 3 phase

Current:
1 = 16A
3 = 32 A

number of branches (if applicable)

wiring type:
2 = Single phase 2 branches
3 = Single phase 3 branches
4 = Single phase 4+ branches
6 = Three phase 6 branches
7 = Idem, alt. phase seq.
X = Definilink input metering
I = Input metering
0 = Legacy

POS	1	2	3	4	5	6	7	8	9	10	11
VALUE	S										

SPIS CODE